

Contents

SYMBOLS AND ABBREVIATIONS	xxiii
ACKNOWLEDGMENTS	xxvi
ABOUT THE AUTHOR	xxix
CONTACT INFORMATION	xxix
DISCLAIMER	xxx
PART I CRYOSTAT DESIGN AND MATERIALS SELECTION	1
1 Introduction to Measurement Cryostats and Cooling Methods	3
1.1 Introduction	3
1.1.1 Organization of the book	4
1.1.2 The last step	5
1.1.3 Extra items	6
1.2 Cryogenic liquids	6
1.2.1 Pumping and pressurizing techniques for changing the bath temperature	9
Pumping	10
Pressurizing	12
1.2.2 Superfluid helium	12
1.3 Introduction to measurement cryostats	14
1.3.1 Checklist/guide to the most relevant sections of this book, depending on cryostat type	15
Temperature	16
Transport current	16
Magnetic field	17
Mechanical properties	18
1.4 Examples of measurement cryostats and cooling methods—low transport current (≤ 1 A)	18
1.4.1 Introduction	18
1.4.2 Dipper probes	19
1.4.3 Liquid-flow cryostats	24
1.4.4 Cryocoolers	25
1.4.5 Pulse-tube cryocooler	26
1.4.6 Gas-flow cryostats	28

1.5 Examples of measurement cryostats and cooling methods—high transport current (≥ 1 A)	30	2.6.3 Pressed contacts and heat switches	65
1.5.1 Immersion test apparatus	30	2.6.4 To grease, or not to grease?	66
1.5.2 Variable-temperature high-current measurement cryostats	32	2.7 Heat conduction across solid/gas interfaces	67
1.5.3 Measurements near the superfluid-transition temperature	32	2.8 Other heat sources	69
Lambda-point refrigerator	33	2.8.1 Joule heating	69
Saturated-liquid-container refrigerator	34	2.8.2 Thermoacoustic oscillations	70
1.5.4 Variable-angle cryostats for measurements in a magnetic field	36	2.8.3 Superfluid-helium creep	71
1.6 Addenda: safety and cryogen handling	37	2.8.4 Adsorption and desorption of exchange gas	71
1.6.1 Safety: how we can go wrong	37	2.9 Examples of heat-transfer calculation	72
Cryogenic problems	37	2.9.1 Case 1: simple dipper probe immersed in liquid helium	72
Less common cryogenic problems	38	2.9.2 Case 2: dipper probe operated in variable-temperature mode in	
Vacuum foibles	39	a superconducting magnet	76
Unhealthy materials	39	2.9.3 Case 3: variable-temperature sample chamber	81
1.6.2 Transferring cryogenic liquids	40	2.10 References	82
Liquid nitrogen	40	2.10.1 Further reading	82
Liquid helium	41	2.10.2 Material property information on the internet	83
Procedure for transferring liquid helium	42	2.10.3 Chapter references	83
Helium-transfer problems	43	3 Cryostat Construction	87
1.7 References	45	3.1 Introduction	87
1.7.1 Further reading	45	3.2 Material selection for cryostat parts	88
1.7.2 Chapter references	46	3.2.1 Room-temperature intuition generally does not work	88
2 Heat Transfer at Cryogenic Temperatures	49	3.2.2 Personalities of materials at low temperatures	90
2.1 Introduction	49	Thermal conductivity	90
2.2 Heat conduction through solids	50	Thermal contraction	92
2.3 Heat conduction through gases (and liquids)	52	Heat capacity	93
2.3.1 Normal pressure (hydrodynamic case)	54	Mechanical properties	94
2.3.2 Low pressure (free-molecule case)	55	Magnetic susceptibility	97
2.4 Radiative heat transfer	55	3.3 Joining techniques	98
2.4.1 Superinsulation/multilayer insulation	57	3.3.1 Introduction	98
2.5 Heat conduction across liquid/solid interfaces	59	Temporary joining techniques	98
2.5.1 Liquid-helium/solid interfaces	59	Permanent joining techniques	100
2.5.2 Liquid-nitrogen/solid interfaces	61	3.3.2 Welding	101
2.6 Heat conduction across solid/solid interfaces	62	3.3.3 Brazing	103
2.6.1 Solder joints	64	3.3.4 Soldering	104
2.6.2 Varnish and glue joints	64	The right flux	106
		Superconducting properties of solder	107

Low-melting-temperature solders	107	4.1.3 AC high-frequency wiring	152
Soldering aluminum—a tough case	108	4.1.4 Wiring installation techniques	153
3.3.5 Sticky stuff	108	4.2 Wire selection	154
3.4 Construction example for a basic dipper probe	109	4.2.1 Wire selection for cryostat design	154
3.5 Sizing of parts for mechanical strength	113	4.2.2 Wire material properties	155
3.5.1 Yield strength	113	4.3 Insulation selection	157
3.5.2 Euler buckling criterion	114	4.4 Heat sinks for instrumentation leads	157
3.5.3 Deflection of beams and plates	116	4.4.1 Wire-anchoring techniques	159
3.5.4 Pressure and vacuum loading	118	4.4.2 Length of wire needed for thermal anchoring	159
3.6 Mechanical motion at cryogenic temperature	120	4.4.3 Beryllium-oxide heat-sink chips	160
3.7 Vacuum techniques and seals for cryogenic use	122	4.5 Solder connections	161
3.7.1 Introduction to cryogenic vacuum technology	122	4.5.1 Solder-joint cracking after repeated thermal cycling	162
3.7.2 Preparing cryogenic vacuum spaces	123	4.5.2 Soldering to thin silver or gold films—the magical disappearing act	162
3.7.3 Leak detectors	124	4.5.3 Superconducting-solder artifacts	162
3.7.4 Cryogenic vacuum seals	125	4.6 Sensitive dc voltage leads: techniques for minimizing thermoelectric voltages	163
Commercial vacuum seals for cryogenic use	126	4.6.1 Connection techniques for low-thermoelectric voltages	163
Indium O-ring vacuum seals	127	4.6.2 Voltmeter connections	165
3.7.5 Vacuum-duct sizing (hydrodynamic flow)	129	4.7 Vacuum electrical lead-throughs	166
3.8 Addenda: high and ultrahigh vacuum techniques	131	4.7.1 Room-temperature lead-throughs	166
3.8.1 Vacuum-duct sizing (free-molecular flow)	131	Nonvacuum connector boxes	167
3.8.2 Pump speed and ultimate pressure	132	Vacuum connector boxes	168
3.8.3 Sources of gas in a vacuum system	135	Vacuum lead-throughs for low-thermoelectric-voltage leads	170
Vacuum vessel leaks	135	4.7.2 Cryogenic vacuum lead-throughs	171
Virtual leaks	135	4.8 Radio-frequency coaxial cables	172
Degassing of materials	135	4.8.1 Heat-sinking	172
Vapor pressure of solids	138	4.8.2 Vacuum-sealing	173
Permeation of gases through materials	140	4.8.3 Superconducting rf transmission lines	174
3.9 References	146	4.9 High-current leads	174
3.9.1 Further reading	146	4.9.1 Copper wire: optimum diameters	174
3.9.2 Properties of solids: internet information	147	4.9.2 Vapor-cooled leads, or how to beat the Wiedemann–Franz–Lorenz law	177
3.9.3 Chapter references	147	4.9.3 Superconductor leads	179
4 Wiring and Connections	150	4.10 Flexible current leads	181
4.1 Introduction	150	4.11 References	182
4.1.1 General guidelines	150	4.11.1 Further reading	182
4.1.2 DC and low-frequency (≤ 10 kHz) wiring	151	4.11.2 Chapter references	183

5 Temperature Measurement and Control	185		
5.1 Thermometer selection (1–300 K)	186	5.5.8 GaAs diodes	221
5.1.1 Thermometer overview	186	5.5.9 Thermocouples	221
5.1.2 Thermometer-selection characteristics	189	5.5.10 Capacitance thermometers	222
5.1.3 General recommendations: examples of thermometer selection for several common measurement situations	192	5.5.11 Carbon resistance thermometers	223
Temperature measurements in zero magnetic field	192		
Temperature measurements in <i>magnetic fields</i>	194		
5.1.4 Small sensing elements	195	5.6 References	223
5.1.5 Thermometry in the presence of nuclear radiation	196	5.6.1 Further reading	223
Gamma radiation	196	5.6.2 Chapter references	225
Neutron radiation	196		
5.1.6 Calibration	196		
5.2 Selection of thermometers for use in high magnetic fields	198	6 Properties of Solids at Low Temperatures	226
5.2.1 Comparison of magnetic errors for commercial thermometers	198	6.1 Specific heat and thermal diffusivity	227
5.2.2 Correcting magnetic temperature error in the best sensors	200	6.1.1 Design data and materials selection	227
5.3 Thermometer installation and measurement procedures	202	6.1.2 Debye model	228
5.3.1 Thermal anchoring of thermometers and their leads	202	6.1.3 Estimating the cost of cooling cryostat parts using the Debye model	230
5.3.2 Thermal anchoring of samples (while maintaining electrical isolation)	204	6.1.4 Thermal diffusivity	231
5.3.3 Thermometer location	206	6.2 Thermal expansion/contraction	233
5.3.4 Thermal radiation and eddy-current heating	206	6.2.1 Design data and materials selection—great differences among resins, metals, and glasses	233
5.3.5 Electrical instrumentation for thermometer sensors	207	6.2.2 Estimating thermal expansion between arbitrary temperatures	238
5.3.6 Operational checkout	208	6.2.3 Calculating thermal stresses	239
Self-heating problems	208	6.3 Electrical resistivity	240
Direct check of the temperature error between thermometer and sample	209	6.3.1 Design data and materials selection: dependence of electrical resistivity on temperature and purity	240
5.4 Controlling temperature	210	6.3.2 Residual resistivity ρ_{res} and defect scattering	241
5.4.1 Pumped liquid refrigerants	210	6.3.3 Ideal resistivity $\rho_i(T)$ and phonon scattering	243
5.4.2 Resistance heaters	210	Bloch–Grüneisen formula: it does not work	244
5.4.3 Temperature controllers	211	Umklapp scattering	245
5.5 Addendum: reference compendium of cryogenic-thermometer properties and application techniques	214	6.3.4 Matthiessen’s rule—a simple method of estimating the total electrical resistivity of nearly pure metals at arbitrary temperatures	246
5.5.1 Platinum resistance thermometers	214	6.3.5 Summary of important points for normal metals	247
5.5.2 Rhodium–iron resistance thermometers	216	6.3.6 Superconductors	248
5.5.3 Germanium resistance thermometers	216	6.4 Thermal conductivity	248
5.5.4 Zirconium–oxynitride resistance thermometers	218	6.4.1 Design data and materials selection	248
5.5.5 Carbon–glass thermometers	219	6.4.2 Electronic thermal conductivity in metals	250
5.5.6 Bismuth–ruthenate and ruthenium–oxide thermometers	219	Wiedemann–Franz–Lorenz law	251
5.5.7 Silicon diodes	220	6.4.3 Phonon thermal conductivity in insulators	252

6.6 Mechanical properties	255	Fuzz buttons	307
6.6.1 Tensile properties	256	Beryllium–copper microsprings	308
6.6.2 Fracture toughness	261	Thin-film transport measurements without patterning	309
6.6.3 Fatigue	262	7.4.4 Requirement 4: voltage taps—noise pickup and current-transfer lengths	311
6.6.4 Creep	264		
6.6.5 Mechanical properties of technical materials: synopsis	264	7.5 Addenda	312
6.7 References	265	7.5.1 Thermal runaway (quench)	312
6.7.1 Further reading	265	7.5.2 Multifilamentary geometry of practical high-current	
6.7.2 Properties of solids: internet information	266	superconductor composites	312
6.7.3 Chapter references	267	7.6 References	315
		7.6.1 Further reading	315
		7.6.2 Chapter references	316
PART II ELECTRICAL TRANSPORT MEASUREMENTS: SAMPLE HOLDERS AND CONTACTS	271	8 Sample Contacts	317
7 Sample Holders	273	8.1 Introduction	317
7.1 General principles for sample-holder design	273	8.2 Definition of specific contact resistivity and values for practical applications	318
7.2 Four-lead and two-lead electrical transport measurements	274	8.3 Contact techniques for high-current superconductors	320
7.3 Bulk sample holders	276	8.3.1 Overview for high-current superconductors	320
7.3.1 Requirement 1: sample temperature uniformity and control	276	8.3.2 Voltage contacts	320
Temperature nonuniformity from variable convective cooling	276	Soldered voltage contacts	321
Temperature nonuniformity from Joule heating	279	Wetting the oxides	321
Practical illustrations of bulk sample holders	280	Pressure contacts	322
7.3.2 Requirement 2: thermal contraction of the sample holder and strain-free mounting techniques	282	Silver paint, paste, and epoxy	323
Choosing a sample holder with a thermal contraction that matches the sample	283	8.3.3 Current contacts for oxide high- T_c superconductors	323
7.3.3 Requirement 3: instrumentation wiring—keep the loop area small	288	Pressed-indium contacts	323
7.3.4 Requirement 4: voltage-tap placement and current-contact lengths	290	High-current contacts—failures	324
Strange voltages of the first kind: the current-transfer length	291	Interfacial chemistry	324
More strange voltages: the twist-pitch effect	293	Fabrication procedures for high-quality HTS current contacts	326
7.3.5 Requirement 5: support your sample!	296	Soldering to noble-metal contact pads	331
7.3.6 Procedures for mounting long superconductor samples	298	Silver-sheathed HTS materials	332
7.4 Thin-film sample holders	301	8.3.4 Measuring contact resistivity	332
7.4.1 Requirement 1: temperature control and uniformity	301	8.4 Contact techniques for film superconductors	333
7.4.2 Requirement 2: stress from differential thermal contraction	303	8.4.1 Overview for film superconductors	333
7.4.3 Requirement 3: lead attachment to the sample's contact pads	303	8.4.2 Contacts for oxide high- T_c superconductor films	334
Wire/ribbon bonds	304	In situ vs. ex situ contacts	334
Pogo pins	306	Cleaning etch	335
		Noble-metal deposition and thickness	337
		Film contact annealing	337
		8.4.3 Measuring film/contact interface resistivity	339

8.5 Example calculations of minimum contact area	341	9.3.2 Critical-current measurement procedures	367
8.5.1 Nb–Ti at 4 K	341	The V – I curve reversal point	368
Contacts immersed in liquid helium	341	Sample stability	368
Contacts in helium gas or vacuum	342	Data-acquisition protocol to avoid sample burnout and ensure good data	368
8.5.2 Nb ₃ Sn at 4 K: resistive-matrix contribution	343	Curve shape: the “who’s who” in problem identification	370
8.5.3 High- T_c superconductors at 77 K	344	9.3.3 Automatic data-acquisition programs	372
Contacts in nitrogen gas or vacuum	346	Introduction and general approach	372
8.6 Spreading-resistance effect in thin contact pads and example calculations	346	Program architecture: simple data loggers	373
8.6.1 YBCO-coated-conductor contacts	347	Program architecture: data acquisition with automated current control	374
8.6.2 Thin-film contacts	348	9.4 Examples of critical-current measurement cryostats	377
8.7 References	349	9.4.1 Critical current vs. magnetic field	378
8.7.1 Further reading	349	9.4.2 Critical current vs. the angle of magnetic field	378
8.7.2 Chapter references	350	9.4.3 Critical current vs. temperature	380
PART III SUPERCONDUCTOR CRITICAL-CURRENT MEASUREMENTS AND DATA ANALYSIS	351	Low-current variable-temperature cryostats	380
9 Critical-Current Measurements	353	High-current variable-temperature cryostats	381
9.1 Introduction	353	9.4.4 Critical current vs. axial strain	383
9.1.1 Transport method vs. contactless methods of measuring critical current	354	Stress-free cooling cryostats	384
9.1.2 Defining critical-current density	355	Bending-beam cryostats	386
9.1.3 The overall picture: dependence of critical current on magnetic field, temperature, and strain	357	Variable-temperature strain measurements	388
9.1.4 Test configurations	359	Ring-coil hoop-stress measurements	388
Transmission-line applications	359	9.4.5 Critical current vs. bending strain	391
Magnet and rotating-machinery applications	359	9.5 References	392
Thin-film electronic applications	360	9.5.1 Further reading	392
9.2 Instrumentation	361	9.5.2 Chapter references	393
9.2.1 Setting up a critical-current measurement system	361	10 Critical-Current Data Analysis	395
Sample current supply	362	10.1 Practical critical-current definitions	396
Thermal-runaway protection circuits	363	10.1.1 Electric-field criterion	396
Voltmeter	364	10.1.2 Resistivity criterion	399
Magnet power supplies	364	10.1.3 Offset criterion	400
Pulsed-current measurements	365	10.1.4 Summary of the advantages and disadvantages of the different criteria	402
9.2.2 Wiring check-out for a new system	366	10.1.5 Transforming to a more sensitive criterion	403
9.3 Measurement procedures	366	10.2 Current-transfer correction	404
9.3.1 General troubleshooting tips	367	10.2.1 Introduction	404
		10.2.2 Back-extrapolation correction method: extend the V – I curve to high voltage	405
		10.2.3 Baseline method: what to do if thermal runaway prevents extending the V – I curve to high voltages	407
		10.3 Magnetic-field dependence of critical current	408
		10.3.1 Introduction	408

10.3.2 General function for the magnetic-field dependence of critical current in low- T_c superconductors	412	10.7.4 Methods for determining parameter values	474
10.3.3 Method for magnetic-field interpolations and extrapolations	413	10.7.5 Transformation method for simplified application of the unified scaling law	478
10.3.4 Effect of B_{C2} inhomogeneity on the shape of the I_c - B characteristics of low- T_c superconductors	418	Unified-scaling transformations	479
10.3.5 Effect of weak links on the shape of the I_c - B characteristics of high- T_c superconductors	419	Intrinsic peak range ($-0.5\% < \varepsilon_0 < +0.4\%$)	480
10.3.6 Improvement of I_c - B characteristics from grain alignment in high- T_c superconductors	421	High-compressive-strain range	481
10.4 Temperature dependence of critical current	424	Example: transformation method for calculating combined strain-and-temperature changes in the critical current	482
10.4.1 Introduction	424	10.8 References	485
10.4.2 Critical field vs. temperature	424	10.8.1 Further reading	485
10.4.3 Critical current vs. temperature	425	10.8.2 Chapter references	486
10.4.4 Linear method for calculating temperature changes in the critical current	426		
10.5 Strain-induced changes in the critical current	432	Appendices	491–626
10.5.1 Introduction	432	Data handbook of materials properties and cryostat design	
Reversible strain effect	434	(see inside back cover for appendix contents)	
Irreversible strain limit	436		
10.5.2 Bending strain effects	437	INDEX	627
10.5.3 Axial-strain effects	439		
10.5.4 Strain scaling law for low- T_c superconductors	440		
10.5.5 Nearly universal effect of strain on the upper critical field	442		
10.5.6 High-compressive-strain range	446		
10.5.7 Example: application of the strain scaling law	449		
10.6 Transformation method for simplified application of scaling relations	456		
10.6.1 Transformation method	456		
Stain-scaling transformations	458		
10.6.2 Example: transformation method for calculating strain changes in the critical current	459		
10.6.3 Temperature scaling law	461		
Temperature-scaling transformations	462		
10.7 Unified strain-and-temperature scaling law and transformations	464		
10.7.1 Unified scaling law—basic relation	464		
Separable form	466		
10.7.2 Parameterization of the unified strain-and-temperature scaling law over the intrinsic peak range ($-0.5\% < \varepsilon_0 < +0.4\%$)	468		
10.7.3 General parameterization of the unified strain-and-temperature scaling law for strains extending to high compression ($\varepsilon_0 < -0.5\%$)	471		